

IHS 8



70 x 65,5 x 43,6

IHS 800



80 x 75,5 x 78,6

IHS 1200



120 x 75,5 x 78,6

IHS 1400



140 x 75,5 x 78,6

IHS 1600



160 x 75,5 x 78,6

IHS 1800



180 x 75,5 x 78,6

ERGI 2005-L



160 x 75,5 x 110 (78,6 x 60)

ERGI 2005-P



160 x 75,5 x 110 (60 x 78,6)

IHS 200
jednací stůl



200 x 75,5 x 110

ERGI 1800-L



180 x 75,5 x 120 (78,6 x 42)

ERGI 1800-P



180 x 75,5 x 120 (42 x 78,6)

ERGI 1000-L



180 x 75,5 x 100 (78,6)

ERGI 1000-P



180 x 75,5 x 100 (78,6)

IHS 150
jednací stůl



150 x 75,5 x 90

IHS 1200 1



120 x 75,5 x 78,6

IHS 1200 2



120 x 75,5 x 78,6

IHS 1600 1



160 x 75,5 x 78,6

IHS 163 1



78,6 x 75,5 x 78,6

IHS 161 2



78,6 x _ x 78,6

IHS 162 2



78,6 x 75,5 x 78,6

IHS 163 2



78,6 x 75,5 x 78,6

IHS 20-L



98 x 75,5 x 103

IHS 20-P



98 x 75,5 x 103

IHS 21-L



ø 100 x 75,5 x (60 x 60)

IHS 21-P



ø 100 x 75,5 x (60 x 60)

IHS 22-L






























ø 120 x 75,5 x (78,6 x 60)

IHS 22-P



ø 120 x 75,5 x (60 x 78,6)

<p>IHSN 1600*</p>  <p>160 x 75,5 (175) x 78,6</p>	<p>ERGI 60-L</p>  <p>160 x 75,5 x 110 (60 x 60)</p>	<p>ERGI 60-P</p>  <p>160 x 75,5 x 110 (60 x 60)</p>	<p>ERGI 80-L</p>  <p>160 x 75,5 x 110 (60 x 78,6)</p>	<p>ERGI 80-P</p>  <p>160 x 75,5 x 110 (78,6 x 60)</p>																						
<p>ERGI 1800 H-L</p>  <p>180 x 75,5 x 200 (78,6 x 42)</p>	<p>ERGI 1800 H-P</p>  <p>180 x 75,5 x 200 (42 x 78,6)</p>	<p>ERGI 1800 HR-L</p>  <p>180 x 75,5 x 200 (78,6 x 42)</p>	<p>ERGI 1800 HR-P</p>  <p>180 x 75,5 x 200 (42 x 78,6)</p>																							
<p>IHS 1600 2</p>  <p>160 x 75,5 x 110</p>	<p>ERGI 1200</p>  <p>120 x 75,5 x 60</p>	<p>ERGI 121</p>  <p>120 x 75,5 x 120 (78,6 x 78,6)</p>	<p>ERGI 122</p>  <p>120 x 75,5 x 120 (78,6 x 78,6)</p>	<p>ERGI 123</p>  <p>120 x 75,5 x 120 (78,6 x 78,6)</p>	<p>IHS 161 1</p>  <p>78,6 x _ x 78,6</p>	<p>IHS 162 1</p>  <p>78,6 x 75,5 x 78,6</p>	<p>KRYCÍ PLECHY</p> 																			
<p>IHS 451</p>  <p>78,6 x _ x 78,6</p>	<p>IHS 452</p>  <p>78,6 x 75,5 x 78,6</p>	<p>IHS 453</p>  <p>78,6 x 75,5 x 78,6</p>	<p>IHS 601</p>  <p>78,6 x _ x 78,6</p>	<p>IHS 602</p>  <p>78,6 x 75,5 x 78,6</p>	<p>IHS 603</p>  <p>78,6 x 75,5 x 78,6</p>	<p>ERGI 120</p>  <p>120 x 75,5 x 40</p>	<p>ERGI 160</p>  <p>157,2 x 75,5 x 60</p>	<p>IHS 14</p>  <p>78,6 x 75,5 x 40</p>	<p>ERGI 30</p>  <p>60 x 75,5 x 30</p>	<table border="0"> <tbody> <tr> <td>KP 8</td> <td>37 x 35</td> </tr> <tr> <td>KP 800</td> <td>47 x 35</td> </tr> <tr> <td>KP 1200</td> <td>87 x 35</td> </tr> <tr> <td>KP 1400</td> <td>107 x 35</td> </tr> <tr> <td>KP 1600</td> <td>127 x 35</td> </tr> <tr> <td>KP 1800</td> <td>147 x 35</td> </tr> <tr> <td>KPE 700</td> <td>47 x 35</td> </tr> <tr> <td>KPE 1300</td> <td>99 x 35</td> </tr> </tbody> </table>	KP 8	37 x 35	KP 800	47 x 35	KP 1200	87 x 35	KP 1400	107 x 35	KP 1600	127 x 35	KP 1800	147 x 35	KPE 700	47 x 35	KPE 1300	99 x 35
KP 8	37 x 35																									
KP 800	47 x 35																									
KP 1200	87 x 35																									
KP 1400	107 x 35																									
KP 1600	127 x 35																									
KP 1800	147 x 35																									
KPE 700	47 x 35																									
KPE 1300	99 x 35																									

* IHSN 1600 nesmí stát samostatně v prostoru. Pouze u zdi či dva stoly IHSN 1600 zády k sobě!

Rozměry jsou v pořadí šířka x výška x hloubka